

Spreader settings and application rates

Gronamic

Golf 16-3-6+2MgO+0.5Fe | Golf 5-0-22+2MgO+0.5Fe

Applicable for the following ICL spreaders: **AccuPro 2000, SR-2000**

	Cone setting	Spread width	Rate and Setting					
			15 g/m ²	20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²
Single Pass	7	4 m	J½	L	M½	O	P½	R
Double Pass (half rate)	7	4 m		I	J	J½	K½	L

Applicable for the following ICL spreaders: **AccuPro One**

	Slider plate	Spread width	Rate and Setting					
			15 g/m ²	20 g/m ²	25 g/m ²	30 g/m ²	35 g/m ²	40 g/m ²
Single Pass	Closed	2 m			13	14	15	16
Double Pass (half rate)	Closed	2 m			9	10	11	12

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.