

# Spreader settings and application rates

## Gronamic Preseeder | Sport

Applicable for the following ICL spreaders: **AccuPro 2000, SR-2000**

	Cone setting	Spread width	Rate and Setting					
			15 g/m <sup>2</sup>	20 g/m <sup>2</sup>	25 g/m <sup>2</sup>	30 g/m <sup>2</sup>	35 g/m <sup>2</sup>	40 g/m <sup>2</sup>
Single Pass	6	4 m	O	Q	S½	V½		
Double Pass (half rate)	6	4 m		M	N	O	P	Q

Applicable for the following ICL spreaders: **AccuPro One**

	Slider plate	Spread width	Rate and Setting					
			15 g/m <sup>2</sup>	20 g/m <sup>2</sup>	25 g/m <sup>2</sup>	30 g/m <sup>2</sup>	35 g/m <sup>2</sup>	40 g/m <sup>2</sup>
Single Pass	Open	2,5 m			17	19	21	22
Double Pass (half rate)	Open	2,5 m			13	14	15	16

The spreader settings are guidelines only. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.